


AMP

H O U S E

11TH FLOOR



3rd Floor North

See 10th Floor North for
indicative layout

2nd Floor South


See 9th Floor South for
indicative layout

Not to scale. For indicative purposes only.

AMP

H O U S E

10TH FLOOR



3rd Floor North

See 10th Floor North for
indicative layout

2nd Floor South


See 9th Floor South for
indicative layout

Not to scale. For indicative purposes only.

AMP

H O U S E

9TH FLOOR



3rd Floor North

See 10th Floor North for
indicative layout

2nd Floor South


See 9th Floor South for
indicative layout

Not to scale. For indicative purposes only.

AMP

H O U S E

6TH FLOOR



3rd Floor North

See 10th Floor North for
indicative layout

2nd Floor South

See 9th Floor South for
indicative layout

Not to scale. For indicative purposes only.